

# Poet BE



## The practical reading device with a book edge.

If you read a lot or use lots of different books then you need a device that allows you to read bound books without breaking the binding. Poet BE (BookEdge) does just that. It allows any page to lie flat on the surface of the scanner. Just press one button and it recognizes all the text including reading into the crease of the book. It is so easy to use that you can even operate Poet BE even if you have had no prior training on the device. With the single press of a button, it reads in a clear and human-like voice.

- Easy to operate
- Reads intelligibly and in a human-like voice
- Practical book edge scanning
- Recognizes entire pages
- Ideal for dedicated readers
- Reads close to the joints of books
- Treats the spine of books with care
- Large scanner

Poet BE is a practical reading device, which can be operated easily and without prior knowledge of its features. Books can be laid over the edge of the scanner with the pages flat without ruining the book. Poet BE recognizes the entire page and reads right into the binding. Up to A4 size books can be read easily. Place the book with its joint flush against the edge of the scanner: press a button and after a short recognition process it will read to you in a comfortable speech with a human-like voice. The advanced software of the Poet BE allows full control over the reading e.g. speed, volume, pausing, and jumping between text passages, these are standard. Experienced users can modify and expand the way they operate according to their needs.



The book edge allows the entire page to lie flat on the scanner.



The controls are easy to operate.



Large books can also be read in their entirety, including the text close to the binding.

### Technical Specifications:

Features:	on/off switch, 5 controls
Scanner:	integrated flatbed scanner with a book edge. The cover is mounted along the longitudinal edge
Text recognition:	OCR, most up-to-date human quality speech output
Size:	45x28x11,5 cm (l×w×h)
Weight:	5.3 kilo with adapter (adapter: 560 g)
Voltage:	100-240V 50/60 Hz

### For further details:

BAUM Retec AG  
Schloss Langenzell  
D-69257 Wiesenbach

Telefon: +49 (0) 6223 4909-0  
Fax: +49 (0) 6223 4909-399  
E-Mail: [info@baum.de](mailto:info@baum.de)  
Internet: [www.baum.de](http://www.baum.de)